




Reset communication settings

What to do when you need to reset the AQM's communication settings back to their factory defaults.

Written By: Tanya Taylor



INTRODUCTION


Use this procedure if you don't see the **Normal Operation** status after 10 minutes of first connecting, or the WIFI SSID name or password have been incorrectly entered and the ePC cannot establish a connection to the local Wi-Fi network.



TOOLS:


- [USB flash drive](#) (1)
-

Step 1 — Insert Aeroqual flash drive




- If you have the Aeroqual USB flash drive that shipped with your monitor, go straight to step 4.
- ① This drive contains the **resetnetwork.aqm** file you need for this procedure.

Step 2 — Create reset file




- If you've lost the USB flash drive that shipped with your monitor, insert another USB flash drive into your computer.
- Create an empty Text document file on the flash drive and name it **.resetnetwork.aqm**
 - ⓘ The file name must have a “dot” at the beginning and the extension must be .aqm.
- Check the **Type** column to make sure it is an **AQM file**. You might need to unhide file extensions and delete .txt from the end of the file name.

Step 3 — Run file on ePC



- Insert the flash drive into any of the USB ports on the monitor's embedded PC (ePC).
- For the AQY 1 specifically; unplug the modem to use the USB port.
- Wait several minutes for the **.resetnetwork.aqm** file to run and the ePC to reboot automatically.

Step 4 — Select Wi-Fi network



- Select the Wi-Fi network that matches the serial number of the unit and enter the password **Aeroqual**.
 - ⓘ Some older units may show "Aeroqual AQM" rather than the serial number.
- Remove the USB flash drive.

Step 5 — Video of Steps



- This process is applicable to all Aeroqual Monitors.
- This video goes over the Network Reset process, including the extra AQY1 step.

For further support, contact [Technical Support](#).