
Reservoir cap replacement

How to remove and install a reservoir cap on 56mm shocks

Written By: Sebastien Blain





Step 1 — Removing protector cap



- Using the appropriate tool, unscrew to protector cap.

Step 2 — Removing reservoir cap







- ***WARNING*** Reservoir contain high gas pressure. Be sure the pressure is released before removing the cap.
- Push de internal valve to remove nitrogen pressure.
- Remove retaining ring and pull the cap out with the appropriate tool.

Step 3 — Installing new cap





- Apply some grease on the o-ring and push the cap Inside the reservoir.
- Re-install the retaining ring , and make sure it is sit in is groove

Step 4 — Charging reservoir




- Charge the reservoir at 200 psi of nitrogen.
- Install the protective cap.