Touchpad Module

Written By: Iroh



INTRODUCTION

Follow this guide to remove and replace the Touchpad Module in your Framework Laptop 16.

TOOLS:

- Framework Screwdriver (1)

PARTS:

- Touchpad Module (Framework 16) (1)

Step 1 — Unlock the Input Modules





- Use your fingernail to pull out the two Input Module latches and unlock them.
  - ⓘ The latch will show red if it's unlocked.

Step 2 — Remove the Touchpad Module





- Use your fingers to slide the Touchpad Module toward the bottom edge of the laptop and disconnect it.
  - ⓘ If you're having trouble, check if the Input Module latches are properly unlocked.
- Lift the Touchpad Module and remove it.

Step 3 — Install the Touchpad Module




- Place the Touchpad Module flat on its cutout so its clips are properly aligned.
- Press the Touchpad Module down and slide it into place so it lines up evenly with the bottom edge of the laptop.

Step 4 — Lock the Input Modules





- Push the Input Module latches back into place to lock them.

If you need help, contact Framework support.