



CFMOTO UFORCE U10 2026+ (ALL TRIMS)

P-LK-253041

Written By: Laurent Metivier



Step 1 — Installing new front Elka shocks



- Remove OEM shocks.
- Install piggyback shock with the reservoir upward and facing the front of the vehicle.
- Install the IFP shock with the head upward.
- The lower rebound adjuster need to be oriented facing the rear of vehicle. Eyelets can be turned manually.

Step 2 — Installing new rear Elka shocks



- Remove OEM shocks.
- Install piggyback shock with the reservoir upward and facing outside of the vehicle.
- Install the IFP shock with the head upward.
- The lower rebound adjuster need to be oriented facing the rear of vehicle. Eyelets can be turned manually.

