

GEOTAB®

BMW 2025+ adapter 9 work around

Written By: Jason Fox



INTRODUCTION

steps to secure adapter 9 in a 2025+ BMW.

— BMW 2025+ adapter 9 work around



- We have discovered on the 2025+ BMW that the adapter 9 from HRN-GS16K22-A doesn't clip into place correctly so it needs to be secured with cable ties.
- Use 2 cable ties to secure the adapter 9 to the vehicle by going through the holes in the adapter then around the piece that holds it.

⚠ **WARNING!** All in-vehicle devices and related cabling must be securely fastened and kept clear of all vehicle controls, including gas, brake and clutch pedals. To ensure all devices and cabling remain securely attached, inspect devices and cabling on a regular basis.

⚠ Loose cabling or devices may impede the use of vehicle controls, resulting in unanticipated acceleration, braking, or other loss of vehicle control, which could lead to death or serious personal injury. Upon sudden acceleration or deceleration, improperly fastened, in-vehicle devices may detach and impact operators, which may cause injury.