




G2 3600 FM Door Installation

Written By: Todd Lucas



Step 1 — Review Product and Warnings

ATTENTION

Thank you for purchasing from Goff's Enterprises, Inc. To ensure maximum functionality and longevity of your product, please carefully review and understand this guide.

SAFETY WARNING


READ THIS MANUAL CAREFULLY. MOST INSTALLATION REQUIRES A LADDER AND TWO PEOPLE AT A MINIMUM. WEAR PROPER SAFETY GEAR AND CLOTHING. OBSERVE WARNINGS AND PRACTICE CAUTION WHEN INSTALLING, OPERATING, OR MAINTAINING YOUR PRODUCT. FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY.

ADDITIONAL SUPPORT

For additional assistance after reviewing this instruction, please reach out to our Technical Support Team using the contact information.


- **Technical Support Contacts:**
- Phone: 262-746-3374
- Email: techsupport@goffscw.com
- Website:
<http://www.goffsenderprises.com>

Step 2 — Measure Opening and Mark the Centerline




- Measure the Opening Width near the top of the Opening.
- Divide that overall width measurement in half to find the Centerline location.
- Clearly Mark the Centerline location.

Step 3 — Measure Door Header Width




- ① The Header Measuring Process is identical for all Door Models. The Door Model you are installing may be different from the Model shown.
- Place the Door roll Header Assembly across a safe and level work surface, and rotate the roll assembly frame so that the Header Bracket Mounting flanges are facing upward.
- Measure the total width of the whole roll assembly from outermost edge of one Header Bracket's Mounting flange to the outermost edge of the opposite side.
- Divide that number by 2. This number is 1/2 of the Header Width, and is used to determine the Header location on the Left and Right Sides of the opening.

Step 4 — Mark the Header Width on the Opening




- Mark this dimension on each side of the Opening Center mark.

Step 5 — Measure Track Height





- Lay one of the Vertical Track Assemblies on your work surface.
- Measure the Length of the Aluminum Track only.
- Add 1/4" to the Track dimension.
- This is the Height dimension needed to mark the location of the Bottom edge of the Header Mounting Brackets.

Step 6 — Mark the Track Height on the Opening




- Add a Horizontal line on each side of the Opening that intersects the previously drawn Vertical line.

Step 7 — Raise and Attach Roll Header Assembly



- Using two (2) people, and two ladders at minimum, raise the Roll Header Assembly to fit between, and above, your markings on the wall.
- Trace the insides of the Header Bracket's three (3) mounting slots onto the wall surface.
- Be sure that the Mounting Bracket's bottom edge is on the height line, and that the outer edge is on your vertical/width line.
- Predrill pilot holes for the mounting hardware at the centers of the traced locations. Using adequate mounting screws or bolts (depending on your building/surface material) to attach the Roll Header Bracket to each side of the opening.
- Raise the Roll Header Assembly into place on the wall, and loosely secure with three (3) sets of mounting hardware per side using screws or bolts that are adequate to your building/surface material.
- Check the Header Assembly for level, and fully tighten all six sets of hardware.
- At this point leave the Roll Assembly tied off and held in place as it comes.

Step 8 — **Optional** - Mount Track Extensions




⚠ If you would like to mount the optional Track Extensions, please refer to the supplemental Track Extension installation instruction before proceeding. If not, proceed to the next step.

Step 9 — Overview Notes - G2 Track Installation



- ⚠ The Track mounts to the Outside of the Tab of the Header Mounting Bracket.
- ⚠ It is important to insert the Carriage Bolt from the Inside of the Header Bracket, and to install the Washer and Hex Nut on the Outside of the Track.
- ⚠ The Track must be plumb before securing it to the Mounting Surface.

Step 10 — Prepare the Track Assemblies




- Attach a Track Mounting Bracket to the Track in the hole located at the bottom.
- NOTE: For extreme cases, such as “High Wind Loads”, an additional Track Mounting Bracket (supplied) will be necessary.
- Mark and Drill the Track (.28-.31 dia) at 1.44” in from the front edge (i.e. centered in the groove), at about mid-height of the Track.

Step 11 — Mount the Track Assemblies




- ① The Track assembly mounts to the outside of the tab of the Header Assembly Mounting Bracket.
- Insert the Carriage Bolt through the Header Bracket Tab from the inside.
- Move the Track to the Outside of the Header Bracket, then push the Bolt fully through the Square hole in the Tab and the Track.
- Slide the Washer onto the Bolt from the outside of the Track.
- Then snug the Hex Nut on the Bolt.

Step 12 — Fasten Track to Wall



1) MOUNT
TRACK
TO HEADER

2) MOUNT
TRACK
BRACKETS
TO WALL



1) MOUNT
TRACK
TO HEADER

2) MOUNT
TRACK
BRACKETS
TO WALL


- Plumb each Track.
 - Fasten the Tracks to the Mounting Surface through the Mounting Brackets.
- ⚠ Keep the Material and Roll-Tube tie wrapped until the Motor is Powered and ready to have the Limits Set.

Step 13 — G2 3600 Door Warranty

3-year limited warranty from failure in normal use due to defects in material and workmanship. This warranty includes the electric motor and all parts and warranty related labor as approved by Goff's tech support team. Goff's reserves the right to repair or replace warranty items at its discretion.

- Technical Support Contacts:
- Phone: 262-746-3374
- Email: techsupport@goffscw.com
- Website:
<http://www.goffsenterprises.com>

Step 14 — Operator Prep



- Carefully remove the Operator from its Shipping Carton, and Remove the Fasteners that secure the Operator to the Backing Plate (plywood).
- Open the Accessory Box and locate the 14 Tooth output Sprocket and 1/4" Key (if not already installed).
- Install the Sprocket on the Operator Output Shaft and tighten firmly.

⚠ It is important to install the Sprocket before the Operator is Mounted to your Mounting Surface/Wall.

Step 15 — Operator Mounting Info


- The Operator (Motor and Reduction Assembly) will be secured to your Building Fascia using 5/16" Fasteners (bolts, lag screws, studs, etc..).
- ⚠ Select fasteners that are not only right for your specific Building Material, but also that can endure Repeated Loosening and Tightening.
- ⚠ It may be necessary to Loosen/Tighten these Fasteners a number of times in order to achieve proper initial Chain Tension and to later adjust for Chain Stretch and Wear.
- ① The use of Washers between the Heads of the Fasteners and the Metal Brackets on the Operator is Strongly Recommended.

Step 16 — Operator Installation Part 1



- Tape the two pieces of the Operator Installation Template together making sure to properly align the Index Mark (bottom of page #1, top of page #2).
- Cut along the indicated Dotted Lines and Remove the section of the Template that corresponds to the Right-Hand Mounting Bracket of the upper box assembly
- Align the Template with the Right Header Bracket on the Upper-Box Assembly and Transfer the four (4) Hole Locations for the 5/16" Fasteners to your Building Fascia.
- Carefully lift the Operator in place and Secure it to your Building using four 5/16" Fasteners. Do not fully tighten the Fasteners at this Point.
- ⚠ Slide the Operator "up" until the Fasteners are at the Bottoms of the Mounting Slots, and Tighten the Fasteners Snugly enough to stop the Operator from Sliding back Down.
- ① Your installation should resemble the following photo


Step 17 — Operator Installation Part 2



⚠ Check the Alignment of the two Sprockets.


- They should be in direct Vertical Alignment. If not, Loosen the Set Screws on either of the Sprockets and Adjust its Position until it is in line with the other Unit.
 - Locate the #41 Chain and Install it over the two Sprockets. Secure the ends with the included Master Link.
 - Loosen the four Fasteners that Secure the Operator to the building Fascia and allow the Weight of the Operator to establish the Tension in the Chain.
- ⚠ Make sure that the Front and Rear runs of the Chain are “Taught” (slightly rotate the roller tube by hand if necessary).
- ⚠ Make sure that the Sprockets are still in Alignment and Tighten the four Fasteners.

Step 18 — Manual Hand Chain Assembly



- Mount the Chain Bracket to the building Wall directly below the Release-Chain at a convenient Elevation (usually about 4' from the floor). Route the Release-Chain through the Keyhole Slot.
- ⓘ The Release-Chain can be Trimmed to-Length at any point below the Keeper. We have also included a “T-Handle” which can be optionally Installed below the Chain Bracket. Please see the Operator Instruction Manual for additional Details.
- Route the Hoist Chain over the Hoist Chain Sprocket (Image 2).
- Join the Free ends of the Chain by Opening one of the Links.
- ⓘ The Chain may be Shortened as required to avoid Dragging on the Ground.
- Secure both Runs of Chain to the Keeper by Routing it as shown in the Image 3.
- ⚠ The chain **MUST** be properly secured before going to the next assembly steps.

Step 19 — Pre-Setting the Limits



- Open the Operator's Cover.
 - ⓘ The next Steps will involve Pre-Setting the End Stop (limit) Nuts on the Operator.
- To do this, Lift the Locking Bar out of the way to allow the Notched Nuts to Spin.
- Then Rotate the Metal Notched Nuts until they hit their respective Limit Switch.
- When adjusting an End-Stop, make sure that the other end stop does not accidentally Rotate.
- Pre-set the “OPEN” (left) End-Stop so that the Nut is Flush with the Left End of the Threaded Rod.
- Pre-set the “CLOSE” (right) End-Stop so that the Nut is approximately 1.5” (one and a half inches) from the Right End of the Threaded Rod.
- ⚠ When you are done, make sure that the Notches on both Nuts properly Engage the Locking Lever Bracket.

Step 20

- ⚠ The next step involves releasing the operator brake and using the chain hoist.
- ⚠ Whenever the Operator's Brake is Released, it is important to have the Hand-Chain Secured to the Bracket or held Firmly.
- ☑ The door is not Counter-Balanced, and Failing to Secure the Hand-Chain may allow the Door to Unroll Rapidly, causing Damage to the Assembly.

Step 21 — Cycle the Door with the Manual Chain Hoist

- Remove the Safety/Shipping Vinyl strapping from the Door Roll.
 - Pull down on the Release-Chain until a firm Resistance is felt. This will release the Operator Brake and engage the Chain Hoist.
 - Use the Keyhole feature in the Chain Bracket to hold the Release-Chain in this position. Carefully unhook the Hand Chain from the Bracket and use the Hoist feature to Lower and Raise the Door.
 - As required, Guide the bottom of the Vinyl Door into the Vertical Track Extrusions. Observe the door action and look for any Binds or Interferences that Hinder the Operation of the Door.
- ⚠ Resolve any issues before proceeding on to the next steps. Run the Door Up and Down a number of times with the Chain Hoist. This will allow the Vinyl Door to “relax” and conform to the Roll-Tube. Position the door in the approximate Mid-Point (halfway open) Position, and Re-Secure the Hand Chain to the Bracket and Unlock the Release-Chain.