
G1 Premium Face Mount with Chain Hoist Installation

G1 Premium Face Mount with Chain Hoist Installation 123476

Written By: Todd Lucas



© 2026

Step 1 — Review Product and Warnings

ATTENTION

Thank you for purchasing from Goff's Enterprises, Inc. To ensure maximum functionality and longevity of your product, please carefully review and understand this guide.

SAFETY WARNING

READ THIS MANUAL CAREFULLY. MOST INSTALLATION REQUIRES A LADDER AND TWO PEOPLE AT A MINIMUM. WEAR PROPER SAFETY GEAR AND CLOTHING. OBSERVE WARNINGS AND PRACTICE CAUTION WHEN INSTALLING, OPERATING, OR MAINTAING YOUR PRODUCT. FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY.


ADDITIONAL SUPPORT

For additional assistance after reviewing this instruction, please reach out to our Technical Support Team using the contact information.

Technical Support Contacts:


- Phone: 262-746-3374
- Email: techsupport@goffscw.com
- Website: http://www.goffsenterprises.com

Step 2 — Measure Opening and Mark the Centerline



- Measure the Opening Width near the top of the Opening.
- Divide that overall width measurement in half to find the Centerline location.
- Clearly Mark the Centerline location.


Step 3 — Measure Door Header Width



ⓘ The Header Measuring Process is identical for all Door Models. The Door Model you are installing may be different from the Model shown.

- Place the Door roll Header Assembly across a safe and level work surface, and rotate the roll assembly frame so that the Header Bracket Mounting flanges are facing upward.
- Measure the total width of the whole roll assembly from outermost edge of one Header Bracket's Mounting flange to the outermost edge of the opposite side.
- Divide that number by 2. This number is 1/2 of the Header Width, and is used to determine the Header location on the Left and Right Sides of the opening.


Step 4 — Mark the Header Width on the Opening



- Mark this dimension on each side of the Opening Center mark.

© 2026


Step 5 — Measure Track Height



ⓘ The Track Measuring Process is identical for all G1 Door Models. The Door Model you are installing may be different from the Model shown.


- Set one of the Vertical Track Assemblies on your work surface.
- Measure the Length of the Vinyl Track only.
- ADD 3-1/4” to this number and take note.
- This is the Height dimension needed to mark the location of the Bottom edge of the Header Mounting Brackets.

Step 6 — Mark the Calculated Height on the Opening



- With the Calculated number (Track length + 3-1/4"), add a Horizontal line on each side of the Opening that intersects the previously drawn Vertical line.

Step 7 — Mount the Door Header



⚠ Use two (2) people, and two ladders (at minimum).

- Raise the Roll Header Assembly into place on the wall.
- The bottom and outside edges of the Header Mounting Brackets should fit inside of Marks on the Mounting Surface.
- Transfer the (3) Slot locations, per side, onto the Mounting Surface.
- Prepare the locations for Hardware appropriate to the building material.
- Loosely secure with three (3) sets of mounting hardware per side.
- Level the Header Assembly, and fully tighten all six sets of hardware.

ⓘ At this point leave the Door/Web Roll tied off and held in place as it comes.


Step 8 — Overview Notes - G1 Track Installation

⚠ The Track Transition Bracket mounts to the Inside of the tab of the Header Assembly Mounting Bracket.

⚠ It is important to insert the Carriage Bolt from the inside of the Transition Bracket and the Washer and Hex Nut on the outside of the Header Bracket.

⚠ The Track must be plumb before securing it to the Mounting Surface.


Step 9 — Mount Track to Header



ⓘ The Track assembly mounts to the Inside of the Header Assembly Mounting Bracket.


- From the inside of the Track, Insert the Carriage Bolt fully through the Square hole.
- Move the Track to the Inside of the Header Bracket, then push the Bolt through the Square hole in the Tab.
- Slide the Washer onto the Bolt from the outside of the Header Bracket.
- Then snug the Hex Nut on the Bolt.

Step 10 — Mount G1 Face Mount Track Assemblies



- Remove the Black Plastic Plugs from the Track front. These are Mounting access Holes.
- Use a Level to Plumb the Track and Transfer the Mounting Hole locations onto the Mounting Surface.
- Remove the Track, and Prepare these locations for Hardware Appropriate to the Building Material.
  - ⓘ Most Materials will Require Pre-Drilling Holes to Accept the Necessary Hardware.
- With the Track Assembly Reinstalled and “Hanging” in this position, Plumb the Track to make sure it is Vertically Aligned.
- Secure the Tracks to the Wall with Hardware Appropriate for your Mounting Surface Material.
- Replace Plastic Caps.

Step 11 — Assemble/Install Chain Hoist



- Insert the Long Bolt
- through the Bottom Front hole in the Hoist
- through the Mounting Bracket Hole
- Loosely Secure these with a Lock Washer and Nut.
- Slide the Hoist Assembly onto the Drive Shaft with a Shaft Key.
- Install a Hex Bolt through the Mounting Bracket Slot
- into the End of the Door's Bottom Spreader Bar.
- Fully Tighten the Lock Washer and Nut.