



How to install Front eccentric Bolts

Step-by-step guide to installing front eccentric camber bolts on a Subaru BRZ for alignment adjustment.

Written By: Dung Nguyen

Step 1 — How to install Front eccentric Bolts



- Loosen but do not remove the upper strut bolt.

Step 2



- Loosen and remove lower strut bolt.

Step 3



- Using a 15mm wrench, install the SPC bolt with the big tab facing outward toward the wheel for negative camber or inwards for positive camber.

Step 4



- With the preferred camber settings, tighten the upper strut bolt.
- Once the tire is back on, proceed with proper alignment.
- Once complete with alignment, torque to recommended specs from SPC which is 97 lb-ft.
- Note: DO NOT OVER TORQUE!