



27W-6-333 Intake Snorkel For Civic/Integra

This set of instructions is created to show you how to install the 27WON Intake Snorkel on your 2023+ Acura Integra A-Spec or 2022+ Honda Civic

Written By: Rich Harris



INTRODUCTION

In this installation guide, we have provided step-by-step instructions to install the 27WON Intake Snorkel

Advisory:

- Working under the vehicle requires a safe and sturdy location for the vehicle to sit on jackstands
- Install requires removing or trimming OE bumper ducting
- Integra install requires modification of a bumper bracket. Details are in this guide
- Integra install requires removal or relocation of one of the two horns



TOOLS:

- Flathead Screwdriver (1)
- Phillips Screwdriver (1)
- Optional: Push Clip Removal Tool (1)
- 3/8" Ratchet (1)
- 3 8" Short extension (1)
- 10mm Socket (1)
- Wrench, 10mm (1)
- Blue Masking Tape (1)
- Flashlight (1)
- Jack Stand (2)
- Hydraulic Jack (1)
- Optional: Razor Blade or Scissors (1)
- Integra : Dremel (1)
- Integra : Black Spray Paint (1)



PARTS:

- Snorkel (1)
- Left Snorkel Bracket (1)
- Right Snorkel Bracket (1)
- 10mm Plastic Push Clip (1)
- M6 x1 .0 x12mm flanged bolt (4)
- 2mm Spacer (2)

Step 1 — Getting Started



- First and foremost; **THANK YOU** for becoming a part of the 27WON Family. We hope to **REDEFINE** your experience of the aftermarket with the highest level Parts, Customer Service, Packaging, & Support
- This guide describes a process to install your new Intake Snorkel
- ⚠ This install requires removing or modifying the ducting between the bumper and radiator support
- ⚠ For Integra, this install requires modifying the bumper support bracket

Step 2 — Jack Up Car




- Follow manufacturer recommendations to jack up and support the front of vehicle
- ⓘ The passenger side wheel and tire were removed for clarity but are not required for bumper removal

Step 3 — Prepare Work Space




- Clear space around the front of the car and underneath to have ample space to remove the front bumper
- Pop open the hood and support with hood prop in fully up position

Step 4 — Remove Topside Bumper Hardware - Integra and CTR



- ① FL5 Type R is similar to Integra. Integra shown
- ① If you have another Honda Civic, skip to the next step
- Use a large flathead screwdriver or prying tool to remove the ten (10) push-clips on the top of the bumper
 - These push clips are not removed
- ① The 2nd and 3rd images give you a better view of the clips

Step 5 — Remove Topside Bumper Hardware - Civic




- ❗ If you have a Acura Integra or CTR, skip to the next step
- Use a large flathead screwdriver or prying tool to remove the ten (10) push-clips on the top of the bumper
 - These push clips are not removed
- ❗ The 2nd and 3rd images give you a better view of the clips
- Other Civic trims not shown but process will be similar

Step 6 — Remove Fender Well Hardware - Integra





- ① The passenger side wheel and tire were removed for clarity but not required for bumper removal. Passenger side shown, Driver side similar
- ① If you have a Honda Civic, skip to the next step
- Integra
 - Remove the dome head screw with Philips screwdriver
 - Remove the flat head screw with Philips screwdriver
 - Remove two (2) push clips with flat head screw driver
- Repeat above for other fender well

Step 7 — Remove Fender Well Hardware - Civic




- ① If you have an Acura Integra, skip to the next step
- FL5 Type R
 - Remove one push clip with flat head screw driver
 - Remove three (3) flat head screws with Philips screwdriver
- Civic except Type R
 - Remove two (2) flat head screws with Philips screwdriver
 - Remove one push clip with flat head screw driver
- Repeat above for other fender well

Step 8 — Remove Underside Bumper Hardware



- Integra
 - Use a large flathead screwdriver or prying tool to remove the ten (10) push-clips on the bottom of the bumper
 - Use 10mm socket and ratchet to remove two (2) M6 bolts
- Civic except Type R
 - Use a large flathead screwdriver or prying tool to remove the eight(8) push-clips on the bottom of the bumper
 - Use 10mm socket and ratchet to remove two (2) M6 bolts
 - Use Phillips head screwdriver to remove two (2) screws
- FL5 Type R. Remove six(6) M6 bolts with 10mm socket. Remove twelve(12) push pins with prying tool. Remove one(1) screw with Phillips screwdriver



Step 9 — Prepare to Remove Bumper (Passenger Side)



ⓘ Integra shown. Civic Similar

- Place a strip of blue Painters tape on the each fender as shown
- Place a strip of blue Painters tape on the each fender as shown
- Place a strip of blue Painters tape under each headlight as shown to help prevent any paint scratches from bumper removal

Step 10 — Loosen Bumper (Passenger Side) Part 1



❗ Integra shown. Civic Similar

- Use a forceful but controlled motion with both hands to pop the bumper out of the three fender clips as shown

- Fender Clips

- ☑ The bumper will take some force to remove the first time it comes off. This is ok. You will hear a lot of noise as the tabs pop loose. The bumper is not breaking, just separating. The key here will be to use one swift forceful motion as opposed to a bunch of small tugs

⚠ Do not fully pull the bumper off the car as there is some wiring to unclip later

Step 11 — Loosen Bumper (Passenger Side) Part 2





⚠ Do not fully pull the bumper off the car as there is some wiring to unclip later

- INTEGRA: Use a forceful but controlled motion with both hands to pop the bumper out of the four headlight clips as shown
 - Headlight Clips
- CIVIC: Use a forceful but controlled rocking motion with both hands to pull the bumper out of the five headlight clips. This takes some force the first time
- Do the same for the Driver side of bumper

⚠ Bumper could drop to the ground. Have friend hold the passenger side

Step 12 — Unplug Fog Light and Parking Sensor (Driver Side)




- ① This step is for cars like the Integra that have Honda Sensing Suite and cars equipped with Fog Lights. Skip for other cars
- Use a Flashlight to see behind the driver side bumper that is loosely hanging off the car
- Use your hand to unclip the parking sensor pig tail
- Use your hand to unclip the fog light pig tail
- Repeat above for Passenger side

Step 13 — Unplug Forward Proximity Sensor



- ① This step is for cars like the Integra that have Honda Sensing Suite. Skip for other cars
- Use your hand to unclip the forward proximity sensor pig tail

Step 14 — Remove Entire Bumper from Car



- Grab bumper with both hands near hood latch and walk it off the car
- Set aside bumper in safe place

⚠ Use caution not to scratch paint on bumper


- Integra
- Civic Si
- Civic EX

Step 15 — Remove Entire Bumper from Car




- FL5 Type R

Step 16 — Loosen Intake Inlet



- ⓘ Skip this step for FL5 Type R install
- Use a 3/8" drive ratchet and a 10mm socket to remove two (2) bolts that holds the intake duct
- Use a panel clip tool or flat head screw driver to remove one (1) clip
- ⚠ Plastic clip breaks very easily. Use Caution


Step 17 — Remove Bumper Support Bracket



ⓘ Integra shown. Civic Similar

- Use a 3/8" drive ratchet and a 10mm socket to remove four (4) bolts that hold the bracket to the radiator mount
- INTEGRA ONLY: With your fingers, pinch and remove the plug attached to the bracket

Step 18 — Remove Ducting



ⓘ Civic Si shown. Other cars similar



- Remove the thirteen (13) plastic push clips with a flat head screwdriver or pry tool holding ducting in place

Step 19 — Remove or Relocate Driver Side Horn - Integra Only




- ① If you have a Honda Civic, skip to the next step
- ① One of the two horns is in the way of the Snorkel
- Remove or Relocate the Driver side horn
- ① The other horn will still work

Step 20 — Attach Brackets to Snorkel



- Attach provided left bracket to Snorkel as shown using provided M6 hardware. Let bracket wiggle a bit
- Attach provided right bracket to Snorkel as shown using provided M6 hardware. Let bracket wiggle a bit

Step 21 — OPTIONAL: Trim Ducting




- ❗ You can either leave the ducting off or trim it
- ❗ If you will leave the ducting off the car, skip to next step
- Place Snorkel on vehicle as shown without OEM ducting installed to assess clearance needed
- Trim OEM ducting around the perimeter of where the 27WON Snorkel mounts as shown using a razor blade or similar sharp trimming tool
 - CIVIC EX TRIM: 6 ducting mount points will be lost as shown
 - CIVIC Si TRIM: 6 ducting mount points will be lost as shown
 - INTEGRA and CTR: Similar but not shown

Step 22 — Install Snorkel





- Place Snorkel in car as shown
- Insert provided plastic clip into bumper as shown

Step 23 — Modify Bumper Support Bracket - Integra Only



- ❗ If you have a Honda Civic, skip to the next step
- ❗ The bumper support bracket removed in Step 17 needs to be trimmed a bit
- OE Bracket. Not modified
- OE Bracket. Modified
- Roughly shows removed material
- Set Bumper Support Bracket in place. Notice the interference in the location of the Snorkel
- Trim the metal bumper support bracket with a Dremel or similar tool to achieve desired clearance
- Use black spray paint to cover exposed metal. Let paint dry

Step 24 — Reinstall Bumper Support Bracket





- Place the two (2) provided spacers as shown between bumper bracket and radiator support on the left two mount points
 - ① Using previous wear marks, align bracket to line up with mounting hole
- Carefully place bumper bracket in place
- Secure bumper bracket in the left two spots with OE hardware using 10mm socket and ratchet
- Install but leave the two bolts at Snorkel loose
- Pop proximity sensor plug back in bumper bracket if applicable

Step 25 — Check Inlet Clearance and Install Inlet



- ① FL5 Type R skip to next step
- ① Inlet and Snorkel should not interfere but they can touch
- Secure intake inlet with OE M6 bolts using 10mm socket and ratchet
- Reinstall OE Inlet Clip
- Adjust Snorkel Brackets for optimal space between inlet and snorkel
 - ① Snorkel will move up/down and in/out if hardware is still loose
 - ① Snorkel should sit as low as possible
- Secure Snorkel Bracket Hardware hand tight with 10mm wrench or socket. Tighten all three (3) bolts on each bracket. This will secure the snorkel and the bumper bracket

Step 26 — Secure Snorkel Brackets - FL5




- ① Civic and Integra skip to next step
- Secure Snorkel Bracket Hardware hand tight with 10mm wrench or socket. Tighten all three (3) bolts on each bracket. This will secure the snorkel and the bumper bracket

Step 27 — Note: Check Snorkel Clearance to Bumper

- ① You are about to install the front bumper. During this process it's a good idea to make sure there is proper clearance between the grille and the Snorkel
- ① Civic Si shown. FL5 Type R shown. Other models typically have more clearance between grille and Snorkel
- Snorkel can be touching the grille but should not be deforming it. If it seems like there is a lot of pressure on the grille then revisit Step 24 and 25 and make sure the Snorkel sits as close to the intake as possible
- Alternatively, you can mark the Snorkel at the interference location and easily remove a little material from the Snorkel with a Dremel or similar to improve fitment

Step 28 — Reinstall Bumper - Part 1




- ❗ Integra process shown. Other cars similar. Refer to removal instructions as installation is the reverse of removal
- Make sure fog light plugs are not hanging below skid plate
- Move bumper almost in place and connect proximity sensor
- Continue carefully moving bumper into position until it's nearly lined up with fender on each side
- ⚠ Bumper can get caught on headlights
- Install one push clip to help secure bumper while plugging in fog lights and parking sensors on each side
- Reach between bumper and car to plugs. You may need to lightly pull bumper at corners to create space

Step 29 — Reinstall Bumper - Part 2



- Note locking tabs at upper fenders. Slide each end of bumper into upper fender tabs
- Push four clips under each headlight into place
- Push three clips at each fender into place

Step 30 — Reinstall Underside Bumper Hardware



- Integra
 - Reinstall the ten (10) push-clips on the bottom of the bumper
 - Use 10mm socket and ratchet to reinstall two (2) M6 bolts
- Civic except Type R
 - Reinstall the eight(8) push-clips on the bottom of the bumper
 - Use 10mm socket and ratchet to reinstall two (2) M6 bolts
 - Use Phillips head screwdriver to reinstall two (2) screws
- FL5 Type R see step 8


Step 31 — Reinstall Fender Hardware



❗ The passenger side wheel and tire were removed for clarity but not required for bumper removal

- Reinstall the dome head screw with Philips screwdriver
- Reinstall the flat head screw with Philips screwdriver
- Reinstall two (2) push clips with flat head screw driver
- Civic except Type R
 - Reinstall two (2) flat head screws with Philips screwdriver
 - Reinstall one push clip with flat head screw driver
- FL5 Type R see step 7

Step 32 — Reinstall Topside Bumper Hardware



- ❶ Civic shown, refer to Step 4 for Integra and FL5 Type R
- Reinstall the ten (10) push-clips on the top of the bumper
 - ❶ The 2nd and 3rd images give you a better view of the clips
- Other Civic trims not shown but process will be similar

Step 33 — I Dare You to REDEFINE



- This completes the installation of your 27WON Intake Snorkel
- We hope you were impressed with your 27WON experience and love your new Snorkel for years to come. Email us at sales@27won.com or call us at 571-271-0271 with any questions or concerns
- Please Leave a review here: <https://store.27won.com/honda-civic-acur...>
- Share your experience using #27WON on Instagram and Facebook

