04 Replacing the Battery

This will go over the battery pack and how to replace it.

Written By: Eric Sutter



© 2026

Step 1 — Removing the Battery





- Find the Battery Release Buttons on the left and right of the Mobile Computer.
- Squeeze the Battery Release Buttons on the left and right of the Mobile Computer to release the battery.
- The battery will pop out and can be removed.

Step 2 — Adding the Battery





- Slide in the battery towards the front of the mobile computer.
- Once the battery pack has slid in all the way, press down on it to lock it in place.