



07 - Calibration

Written By: Eric Sutter



Step 1 — Turning on and navigating the printer



- Turn on the printer by pressing and holding the power button until the LED screen lights up and the printer beeps.
- Select the 'Menu' button to the left of the panel
- Press the 'Down' arrow and select 'Sensor.'

Step 2 — Finalizing Calibration



- Select the first option, 'Auto Calibration.'
 - Press the 'Down' arrow once then select 'Black Mark.'
- ⓘ The printer should begin calibration. It will print a few blank labels as part of this process*