



04 - Properly Connecting printer Power and USB Cables

Written By: Eric Sutter





Step 1 — Preparation



- Place the printer on a flat, stable surface.
- Take the plastic film off of the printer, and get the cables out of their packaging.

Step 2 — Identifying the Cables



- USB-C

- USB-A

- ① The USB-B and USB-A are two ends of the same cable. The USB-C to USB-A cable is only used for initial set-up and support. It should **NOT** be used for other purposes.

- Power Outlet Plug

- Printer Power Plug

- ① The Power Outlet Plug and the Printer Power Plug are two ends of the same cable.

Step 3 — USB Connection



- Plug the USB-C into the printer's USB interface behind the Interface Cover.
 - Plug the USB-A into your computer/laptop's USB port.
- ① To correctly identify the USB-C from the USB-A, please refer to the last step.

Step 4 — Power Connection



- Connect the Printer Power Cord into the back of the printer in the power cord socket.
- Once the Printer Power Cord is connected, connect the Power Outlet Cord into a power outlet.

⚠ **DO NOT** turn the printer on without the labels being loaded first. See how to load Direct Thermal labels [HERE](#)