




How to Install and Remove Expansion Cards

Written By: Iroh




INTRODUCTION

This guide shows how to install and remove Expansion Cards for your Framework Laptop.

All official Expansion Cards work fully in all slots , so you can install them however you wish!



The Expansion Cards are hot-swappable. You can install and remove them without turning off your laptop.

Step 1 — Set your laptop down




- Set your laptop face-down on a clean work surface.

Step 2 — Install an Expansion Card




- ① The next two steps show how to install an Expansion Card.
- Slide an Expansion Card into an Expansion Card slot.
 - ① You don't need to unlock the latches to install the Expansion Cards—only when you want to remove them.
 - ① The Expansion Cards should click into place, and the front edge should be flush with the laptop.

Step 3



- If there's a red bar showing under the Expansion Card latch, use your finger to flip the latch and lock the Expansion Card into its slot.
- ① Locking the Expansion Card slots helps keep the cards in place when you unplug cables from them.

Step 4 — Remove an Expansion Card



- ① The next two steps show how to remove an Expansion Card.
- Use your fingers to flip the two Expansion Card latches (one for each side) into the **unlocked** position.
- ① The latches display a red bar when they're unlocked.

Step 5



- Grip the lip of the Expansion Card with your fingers.
- Pull the Expansion Card out of its slot and remove it.
- ① If you have trouble pulling the Expansion Card out, you can also use the flat end of your Framework Screwdriver to push against the lip.

If you need help, [contact Framework support](#).