# Front Panel Tiles

Written By: Iroh



# INTRODUCTION

This guide shows how to install and remove the Tiles on your Framework Desktop.

The Tiles are mainly for decoration; they aren't necessary for your desktop to function.

The Front Panel can support up to 21 tiles.



© 2026 




## Step 1 — Remove the Front Panel





- Use your fingers to pull the Front Panel off the magnets securing it to the chassis.




## Step 2 — Remove the Tiles

- Use your fingers to push the bottom of the Tile up and off the front panel and release its clips.
- Remove the Tile.



© 2026

## Step 3




- Repeat this procedure for the remaining tiles.

## Step 4 — Disassembly complete



- Congratulations on completing disassembly! **The remaining steps will show how to reassemble your Framework Desktop.**

## Step 5 — Install the Tiles

- Tiles can be installed in any orientation, even the ones with graphics.
- Lay a Tile over an open slot on your Front Panel.
- Use your fingers to press the tile into the slot and engage the clips.
  - You'll hear and feel an audible "click" when the clips engage.

## Step 6






- Install the remaining Tiles.

## Step 7 — Install the Front Panel





- Lay the bottom of the Front Panel on the small, protruding lip in the silver base to align its tabs.
- Press the Front Panel flat to the chassis and let it align to the magnets.

If you need help, contact Framework support.