

02 How to Set Up the Laserpoint Vinyl Cutter

Prep the vinyl cutter before sending a job from the software




Step 1 — Adjust the Media Holder



- If you're using a roll of vinyl slide the media holder (in the back of the machine) so that the roll will be centered over the holder.

Step 2 — Load the media



- Place the roll of vinyl on the holder with the open edge going up and facing away from the vinyl cutter
- Make sure that the pinch release roll levers are unlocked (i.e. in the down position)
- Insert the media under the the pinch rollers through to the front of the machine

Step 3 — Align and Secure the Media



- In the back, slide the pinch rollers to about one inch from each edge of the media.
- ❗ Make sure the media is flat and going into the machine as perpendicular as possible.
- Lock the pinch rollers by lifting the levers up.

Step 4 — Turn On



- Turn the machine on--the switch is on the left side.
- ❗ The display will run through startup, then show that it's "On-Line"

Step 5 — Adjust the media and cutting head



- Turn on "Jog Mode" by pressing the "On Line" button once
- Using the directional buttons, feed the media forwards/backwards and the cutting head left and right until it's where you want to start cutting
 - ❗ It's helpful to note the small red laser dot directly under the cutter when aligning the head and media.
- Then press the target button to zero out the starting coordinates

Step 6 — Go Back On-Line



- Insert wisdom here.