

03 - How to Cut with the Laserpoint Vinyl Cutter

How to cut with the vinyl cutter after the design has been made and the machine has been prepared with the material to be cut.




Step 1 — Adjust the Media Holder



- If you're using a roll of vinyl slide the media holder (in the back of the machine) so that the roll will be centered over the holder.

Step 2 — Load the media



- Place the roll of vinyl on the holder with the open edge going up and facing away from the vinyl cutter
- Make sure that the pinch release roll levers are unlocked (i.e. in the down position)
- Insert the media under the the pinch rollers through to the front of the machine

Step 3 — Align and Secure the Media



- In the back, slide the pinch rollers to about one inch from each edge of the media.
- ❗ Make sure the media is flat and going into the machine as perpendicular as possible.
- Lock the pinch rollers by lifting the levers up.

Step 4 — Turn On



- Turn the machine on--the switch is on the left side.
- ❗ The display will run through startup, then show that it's "On-Line"

Step 5 — Adjust the media and cutting head



- Turn on "Jog Mode" by pressing the "On Line" button once
- Using the directional buttons, feed the media forwards/backwards and the cutting head left and right until it's where you want to start cutting
 - ❗ It's helpful to note the small red laser dot directly under the cutter when aligning the head and media.
- Then press the target button to zero out the starting coordinates

Step 6 — Go Back On-Line



- Insert wisdom here.