Instructions for Putting SKSNG in Valet Mode (Remote Start Off)

This guide details how to put SKSNG remote starts in valet mode using the built-in menu. Valet mode will disable the remote start (remote start: off).

Written By: Mid City Support



INTRODUCTION

Valet mode (remote start off) disables the remote start and should be used any time the vehicle is being serviced or is in a condition where it should not be started remotely.


SmartKey Starter® models that apply:

Any part # with ‘NG’ in it with V4.5 and up.

- SKSNG204D3
- SKSNG204D4
- SKSNG205D4
- SKSNG166D3
- SKSNG166D4
- SKSNG205D4
- SKSNG222D4
- SKSNG166D4T
- SKSNG204D4T
- SKSNG447D4T
- SKSNG221D3
- SKSNG166D4KS
- SKSNG907
- SKSNG907RV


Note: for SKSNG907 and SKSNG907RV with vehicles that do not have volume and mute buttons on the steering wheel controls, please refer to this guide here: How To Put SKSNG907, SKSNG907G, SKSNG907RV, SKSNG907RVG in Valet Mode for Vehicles Without VOL / MUTE Buttons On Steering Wheel

Step 1 — Enter vehicle




- Enter vehicle and sit in driver seatd
- Close driver door (make all other doors are closed as well)

Step 2 — Put vehicle in ACC



- **Without your foot on the brake** press the push to start button one time
  - Note: for vehicles without push button start, insert key and turn to the first position

Step 3 — Put instrument cluster on RADIO or AUDIO page



- Press home button on steering wheel, menu will appear (NAVI, TRIP, etc)
- Use directional pad or arrows to highlight RADIO or AUDIO
- Select RADIO or AUDIO
- Instrument cluster should now show radio information on the instrument cluster

ⓘ Make sure that radio is turned on

Step 4 — Enter menu



- To enter the SmartKey Starter® menu, press and hold the **MUTE** button on the steering wheel for approximately 2 seconds
- Instrument cluster will say REMOTE START: ON or REMOTE START: OFF
- Release MUTE button

Step 5 — Turn remote start off



- To enter valet mode (change setting to remote start: off) press and release the MUTE button until the menu says ‘REMOTE START: OFF’
  - ⓘ If the remote start was already on, you will only have to press the MUTE button once
  - ⓘ If the menu already says ‘REMOTE START: OFF’ you can simply wait until the screen says ‘SETTINGS SAVED’


Step 6 — Save settings



- Once you have changed to the preferred setting, save the settings changes by waiting until the menu

times out. When the menu has timed out, the screen will say ‘Settings Saved’

Step 7 — Attempt remote start



- To be sure the system has been put in valet mode (remote start on), press the push to start button twice to turn vehicle completely off and open and close the door
- Once vehicle is completely off, press and release the PANIC button on the OEM remote
- Make sure the vehicle does not start (the parking lights should flash 4X, indicating the system is in valet mode