

Replacing P3's Splice Tube

How to replace Palette 3's splice tube.

Written By: Jonny Yeu





Step 1 — Access Splice Core




- Remove Palette's top lid.

Step 2 — Replacing the splice tube








- Remove the Splice Core's thumbscrew and remove the Splice Core.
- Turn the tab on the Splice Core to pull out the splice tube. Push the old splice tube through the tab.
- Insert the new splice tube into the tab. Holding the tab, push the new splice tube back into the Splice Core


© 2024

Step 3 — Replace Splice Core



- Replace the Splice Core and fasten its thumbscrew.
- Replace the acrylic cover, thumbscrews, and top lid.

Step 4 — Reset Tube Counter



- On Palette's Menu go to *Settings > About > Splice Core > Reset Tube Counter.*
- Proceed with the reset to bring the splice count for this tube back to 0.

© 2024