Lenovo Mini PC - Unboxing

Written By: Brendon Welch



INTRODUCTION

This guide will walk you through unboxing your Lenovo Mini PC, and demonstrate how to maintain the packaging materials incase it needs to be sent back to T2.

© 2024


Step 1 — Lenovo Mini PC - Unboxing



⚠ Be sure to open your PC right side up, and be careful when using a sharp blade.

- **Cut the tape** on the top of the box

Step 2



⚠ To prevent damage to your PC, be sure to remove the items in order.

- Remove the **Mini PC**
- Remove the **Keyboard**
- Remove the **Power Supply and Accessories**

© 2024


Step 3




- Be sure to have enough space to set up all items. Lay all components out to ensure a simple setup.
- Open the **Power Supply and Accessories** box

Step 4







Unwrap each item, and lay them out. Put the power supply box and plastic wrap back in the box.


Refer to this key to identify each item.

- **Wi-Fi Antenna**

Wi-Fi Antenna may be internal on newer models and not included.

- **Mini PC Power Supply**
- **Mini PC Stand**
- **Mini PC Power Supply AC Cable**
- **USB Mouse**


Step 5


Open the keyboard box, and carefully remove the plastic from the keyboard.

- **Pull out the Tabs** in the center of the box
- **Put the plastic wrap back in the keyboard box**

Step 6




- **Hold on to the Mini PC**
- **Remove the cardboard sides**

Step 7







⚠ Be careful when using a sharp blade.

- **Cut the Security Seal**
- **Remove the Mini PC** from the plastic

Step 8

- Put the empty component's boxes and packaging back into the PC's box.
- Replace the **Power Supply and Accessories box**
- Replace the **Keyboard box**
- Replace the **Mini PC packaging**

Step 9



Keep all items organized and laid out.

Wi-Fi Antenna may be internal on newer models and not included.

[CLICK HERE for the ThinkVision Monitor Unboxing]