How It Works: Loading Guard Door

Written By: Randy Sanchez



This document was generated on 2022-01-02 07:43:54 PM (MST).

Step 1 — How It Works (Loading Guard Door)







- The loading guard door provides the ability to slide to the right, away from the spindle to allow easier access to the workpiece or work holding.
- The door is released using the DOOR OPEN button on the apron plate. This button also releases the sliding door from the saddle.

ⓘ In the event that the guard is not properly closed, a “Chuck guard open” message will appear on the control, and the spindle will not be allowed to run, nor will the axis move.