How It Works: Chuck Guard

Written By: Randy Sanchez



© 2022

Step 1 — How It Works (Chuck Guard)







- On the 30120RX, there are four guards; the Chuck Guard, Rear Chuck Door, Part Loading Guard Access Panel and Spindle Motor Access Door.

Loading Guard Door is discussed in its own "How It Works" tutorial. (No Image)

In the event that any of the four guards or door is not properly closed, a “Chuck guard open” message will appear on the control, and the spindle will not be allowed to run.

Step 2 — How It Works (Chuck Guard) Cont.



- Part loading door for reference.