
Evident Fluoview 4000 (Irchel) - Apply settings from an image

Evident Fluoview4000

Written By: z mbstaff




© 2025

INTRODUCTION

This one-step guide will show you how to load settings from the image

© 2025

Step 1 — Apply setting from image



- Open image from which you want to load settings
- Make sure that you are in a image window
- Click on **Load acquisition parameters**