CF MOTO ZFORCE 950 2020

FLS-203010_revB

Written By: Sebastien Blain



Step 1 — Removing the stock shocks



- Lift the vehicle using a jack or stand so that the wheels are off the ground. Refer to your vehicle's owner manual for specific instructions on how to remove the stock shocks. Keep your original bolts to re-use when installing your new Elka shocks.

Step 2 — Installing the new Elka front shocks





- Install the front new Elka shocks with the reservoir facing the rear of vehicle. (left side shown)
- The lower shock eyelets should be installed with the rebound adjuster oriented **towards the rear of the vehicle** as shown by the blue Arrow on the photo (left side shown). If needed, you can turn the lower eyelet to orient properly.

Step 3 — Installing the new Elka rear shocks





- Install the new Elka rear shocks with the piggyback **reservoir facing the ground** and oriented **towards the front of the vehicle** as shown. (right side shown)
- The rebound adjuster located on lower eyelet of the shocks should be oriented **towards the inside of the vehicle**, as shown. (Right side shown). If needed, you can turn the lower eyelet to orient properly.

© 2026