TVI Auxiliary Camera - Universal Bracket Kit - SPR-GFP-UNIVBRK

Written By: Brad Legge



© 2026 - Uncontrolled If Printed

INTRODUCTION

This guide covers the installation of the Universal Bracket Kit for use with the small bracket TVI auxiliary camera and GO Focus Pro. Note: tube style mirror and surface mount options will be added in a future revision.

© 2026 - Uncontrolled If Printed

— In the Kit



- 1 x Universal mounting bracket
- 4 x Universal mounting bracket fasteners
- 2 x Large clamp
- 2 x Small clamp
- 1 x Adhesive backed silicone strip

— Install Universal Bracket to Aux Camera





- Mount the universal mounting bracket to the TVI camera using the 4 included fasteners.

ⓘ A 4mm hex key is required to tighten the fasteners.

ⓘ The flat side of the bracket mounts to the TVI camera.

© 2026 - Uncontrolled If Printed

— Pre-Route Clamps





- Select the appropriate clamp size for the mounting application - large or small.
- Route the selected clamps through the slots on the universal mounting bracket prior to mounting on the vehicle.

© 2026 - Uncontrolled If Printed

— Secure Camera to Vehicle Mirror - Large Aero Style





- Apply the included adhesive backed silicone strip to the bracket contact surface to protect the mirror from damage.

ⓘ The silicone strip can be cut to size and also applied at other clamp-to-surface contact points as desired.

- Using the large clamps, mount the auxiliary camera assembly to the large aero style mirror by routing the clamps around the mirror housing and tightening securely.

ⓘ A 7mm socket or Phillips screwdriver is required to properly tighten the clamp.

- Ensure the camera is positioned for optimal field of view before fully tightening.

ⓘ Refer to the GO Focus Pro with Auxiliary Cameras guide to finalize mounting and complete cable routing.

© 2026 - Uncontrolled If Printed