OpenEVSE

OCPP Setup Pulse Energy

Setup OpenEVSE to connect to the Pulse Energy OCPP server (OCPP 1.6J)

Written By: Christopher Howell

Welcome to Pulse Energy

Login / Register to Access Your Charger

Existing User


Login Via Email

New user

Register Using Email


Step 1 — Create a free account





- With a web browser navigate to https://homecharger.pulseenergy.io/insta
- Create an account.
- Pulse energy allows up to 10 stations in a free account.

Step 2 — Add OpenEVSE charging station




- Click Add New Charger on the Charger Dashboard Screen
- Name your OpenEVSE Station
- Check the "Schedule Charging" and "Limit Power" boxes
- Enter Longitude and Latitude of the station.
- Click Add New Charger

Step 3 — OpenEVSE OCPP Setup









- Copy the OCPP link from Pulse Energy.
- ⚠ OpenEVSE has a separate field for URL and Charger ID. The last part of the URL will be input in the "Charge Box ID".
- Click the Enable Slider on OpenEVSE
- The charger status should now be active on the Pulse Energy page. Its okay if OpenEVSE still says disconnected, we still need to add an ID tag.

Step 4 — Navigate to Pulse Energy Analytics







- Using a web browser navigate to https://homecharger.pulseenergy.io/analy...
- Click the menu icon and select ID Tags
- Copy the ID Tag and paste into OpenEVSE ID-Tag Field. Enable the Authorize checkbox.
- Enable the energize and suspend boxes.

Step 5 — View data on Pulse Energy Analytics



 Your station and data should now be live on the Pulse Energy Site. https://homecharger.pulseenergy.io/analy...